



Job Name: _____

Job Location: _____

Contractor: _____

Engineer: _____

Approval: _____

Con-Stab® Chamfer Tools

Design Features:

- For Constab® "ID Seal" fittings only
- Pipe Size and SDR Specific
- Made in USA



Follow the arrows printed on the label.
Only 3-5 turns necessary for a good chamfer!

Test Gauge



Before Square-Cut



After Chamfered

Test your chamfer by using the "Test Gauge" on your chamfer tool. The test gauge approximates the o-ring-embedded insert inside each Con-Stab fitting. Test your chamfer by pushing the pipe over the test gauge. If the pipe is chamfered properly, it should fit over the test gauge with minimum effort.

Always Match Pipe Size & SDR

You must use a Continental Chamfer Tool on a Continental Fitting



WR#	Size	Wall Thickness	Weight (lbs.)
2888020	1/2" CTS	.090 Wall	.36
2888014	3/4" IPS	SDR-11	.36
2888016	1" IPS	SDR-11	.43
2888022	1" CTS	.099/.101 Wall	.36
2888006	1-1/4" IPS	SDR-10	.50
2888007	1-1/4" IPS	SDR-11	.50
2888008	1-1/2" IPS	SDR-11	.60
2888010	2" IPS	SDR-11	.80