



Superheat	Subcool	Charge
Good	Good	Good
High	Low	Low
Low	High	Over-Charge
High	High	Restricted
Low	Low	Over-feeding

Only evaluate charge after the airflow has been confirmed to be accurate and coils are confirmed to be clean.

Learn more about Coburn Supply by visiting coburns.com/techservices