


Exploded View



Part Number Guide

Base Faucet Assembly

1	Screw, Seat Washer	000933-45
2	Washer, Seat	001092-45
3	Spindle, RH	000800-25
4	Spindle, LH	000801-25
5	Washer, Brass	000986-45
6	Washer, Rubber	001047-45
7	Washer, Bonnet, Stainless Steel	002726-45
8	Asm, Bonnet	010196-25
9	Washer, Bonnet	009752-45
10	O-Ring, Diverter Stem	001075-45
11	Bonnet	009749-25
12	O-Ring, Nozzle Swivel Piece	001074-45
16	Seat, Removeable	000763-20

Parts Not Included in Kit

13	Handle, Lever	001638-45
14	Button, Index Hot (Red)	001661-45
	Button, Index Cold (Blue)	001660-45
15	Screw, Handle	000922-45
