



700 Series

| BASE MODEL | DESCRIPTION |
|------------|---|
| 700CC | Copper Compression Stop Valves 1/2" |
| 702CC | Copper Compression Stop Valves 1/2" Stop & Waste |
| 725CC | Copper Compression Stop Valves 3/4" |
| 727CC | Copper Compression Stop Valves 3/4" Stop & Waste |

 For available options, use Base Model number and add desired suffix from Legend.



800 Series

| BASE MODEL | DESCRIPTION |
|------------|---|
| 800 | Stop Valve 1/2" FIP Straight Stop |
| 801 | Stop Valve 1/2" FIP Angle Stop |
| 802 | Stop Valve 1/2" FIP Straight Stop and Waste |
| 825 | Stop Valve 3/4" FIP Straight Stop |
| 826 | Stop Valve 3/4" FIP Angle Stop |
| 827 | Stop Valve 3/4" FIP Straight Stop and Waste |

- Add SW after Base Model number for Sweat option.
- For available options, use Base Model number and add desired suffix from Legend.

Evaporative Cooler Faucets



240/245

| BASE MODEL | DESCRIPTION |
|------------|--|
| 240 | Evaporative Cooler Valve 3/4" FIP Inlet x 3/4" Hose with 1/8" Tap |
| 245 | Evaporative Cooler Valve 3/4" Hose Inlet x 3/4" Hose with 1/8" Tap |

 For available options, use Base Model number and add desired suffix from Legend.

Arrowhead Meter Valves



851/871

| BASE MODEL | BASE MODEL |
|------------|--|
| 851 | Meter Valve 3/4" Flared Tube x 3/4" FIP Stop and Waste |
| 871 | Meter Valve 1" Flared Tube x 3/4" FIP Stop and Waste |

- Flared angle pattern stop and waste valves.
- For available options, use Base Model number and add desired suffix from Legend.







