

Manual Ratchet Threaders



EXPOSED RATCHET THREADER SETS

All matched Threader/Sets include Die Heads, Ratchet Assembly, Ratchet Handle and Alloy Dies. All Threader Sets use same 12-R Dies in Die Head.


- Model 00-R: Capacity 1/8" - 1" without carrying case.
- Model 12-R: Capacity 1/8" - 2" with carrying case.

Catalog No.	Model No.	Description	Die Heads Include		Weight	
			in.	mm	lb.	kg
36345	00-R	NPT	1/2 - 1	12 - 25	10	4.5
36355			3/8 - 1	10 - 25	1¼	5.1
36375			1/8 - 1	3 - 25	13¾	6.2
36480	12-R	NPT	1/2 - 1¼	12 - 32	23¾	10.8
36475			1/2 - 2	12 - 50	34¾	15.8
36505			1/8 - 2	3 - 50	45½	20.7
55207*			1/2 - 2	12 - 50	35½	16.1
65175	00-R	BSPT	1/2 - 1	12 - 25	10	4.5
65255	12-R		1/2 - 2	12 - 50	34¾	15.8
65285	12-R		1/8 - 2	3 - 50	45½	20.7
36510		NPSM	1/2 - 2	12 - 50	34¾	15.8

*For plastic-coated pipe

ENCLOSED RATCHET THREADER SETS

- All matched Threader/Sets include Die Heads, Ratchet Assembly, Ratchet Handle and Alloy Dies. All Threader Sets use same 12-R Dies in Die Head.
- No 11-R capacity: 1/8" - 1 1/4".



Model 11-R

Catalog No.	Model No.	Description	Die Heads Include		Weight	
			in.	mm	lb.	kg
36390	11-R	NPT	½ - 1¼	12-32	16	7.3

RATCHET & HANDLE ONLY

- Ratchet knob indicates forward and reverse.
- Die heads snap in from both sides and lock in place.



Catalog No.	Model No.	Description
38540	00-RB & 00-R	Ratchet & Handle Only
37777	11-R	
38550	111-R	
30118	12-R	
38535	0-R	



See page 4.12