

STARTING COLLARS

Size	# 500H		# 500D	
	#500H P/N	CTN	#500D P/N	CTN
4"	500H4	24 ea	500D4	24 ea
5"	500H5	24 ea	500D5	24 ea
6"	500H6	25 ea	500D6	25 ea
7"	500H7	28 ea	500D7	28 ea
8"	500H8	22 ea	500D8	22 ea
9"	500H9	25 ea	500D9	25 ea
10"	500H10	20 ea	500D10	20 ea
12"	500H12	18 ea	500D12	15 ea
14"	500H14	12 ea	500D14	16 ea
16"	500H16	16 ea	500D16	12 ea
18"	500H18	12 ea	500D18	10 ea
20"	500H20	10 ea	500D20	1 ea
22"	500H22	10 ea	500D22	1 ea
24"	500H24	1 ea	500D24	1 ea



500H Metal Starting Collar



500D Metal Starting Collar With Damper

Size	# 500DBH		# 500DBD	
	#500DBH	CTN	#500DBD	CTN
4"	500DBH4	24 ea	500DBD4	24 ea
5"	500DBH5	24 ea	500DBD5	24 ea
6"	500DBH6	28 ea	500DBD6	28 ea
7"	500DBH7	22 ea	500DBD7	22 ea
8"	500DBH8	25 ea	500DBD8	25 ea
9"	500DBH9	20 ea	500DBD9	20 ea
10"	500DBH10	25 ea	500DBD10	25 ea
12"	500DBH12	17 ea	500DBD12	17 ea
14"	500DBH14	12 ea	500DBD14	12 ea
16"	500DBH16	10 ea	500DBD16	9 ea
18"	500DBH18	9 ea	500DBD18	10 ea
20"	500DBH20	1 ea	500DBD20	1 ea



500DBH Ductboard Starting Collar



500DBD Ductboard Starting Collar With Damper

Size	# 501	
	#501 P/N	CTN
4"	5014	20 ea
5"	5015	20 ea
6"	5016	20 ea
7"	5017	20 ea
8"	5018	20 ea
9"	5019	20 ea
10"	50110	20 ea
12"	50112	20 ea
14"	50114	20 ea
16"	50116	20 ea
18"	50118	20 ea
20"	50120	20 ea



501 Ductboard Starting Collar