



# RHLA

Parts List  
03-October-2017



*This parts list is current as of the above revision date.  
See <http://www.rheempartslists.net/92-42800-RHLA.pdf> for the current revision.*

**Air Handlers**

| No.                     | Notes | MODEL<br>CAPACITY<br>CABINET SIZE<br>VOLTAGE         | RHLA          | RHLA          | RHLA          | RHLA          | RHLA          |
|-------------------------|-------|--|---------------|---------------|---------------|---------------|---------------|
|                         |       |  | 24<br>17<br>A | 24<br>17<br>J | 36<br>17<br>A | 36<br>17<br>J | 48<br>21<br>A |
| <b>ELECTRICAL GROUP</b> |       |  |               |               |               |               |               |
| 17                      | Stk   | Transformer  | 46-101944-02  | 46-101905-02  | 46-101944-02  | 46-101905-02  | 46-101944-02  |
|                         |       | Power Factor Choke                                   | N/A           | N/A           | N/A           | N/A           | 46-24256-04   |
| 18                      | Stk   | Control Board  | 47-102077-02  | 47-102077-02  | 47-102077-02  | 47-102077-02  | 47-102077-02  |
|                         | Stk   | Fuse - Control Board                                 | 44-101986-01  | 44-101986-01  | 44-101986-01  | 44-101986-01  | 44-101986-01  |
|                         |       | Wiring Harness - 6 pin to 6 strip leads (For T-Stat) | 45-101891-01  | 45-101891-01  | 45-101891-01  | 45-101891-01  | 45-101891-01  |
| 11                      |       | Terminal Block                                       | 45-23222-02   | 45-23222-02   | 45-23222-02   | 45-23222-02   | 45-23222-02   |

| No.                     | Notes | MODEL<br>CAPACITY<br>CABINET SIZE<br>VOLTAGE         | RHLA          | RHLA          | RHLA          | RHLA          | RHLA          |
|-------------------------|-------|--|---------------|---------------|---------------|---------------|---------------|
|                         |       |  | 48<br>21<br>J | 48<br>24<br>A | 48<br>24<br>J | 60<br>24<br>A | 60<br>24<br>J |
| <b>ELECTRICAL GROUP</b> |       |  |               |               |               |               |               |
| 17                      | Stk   | Transformer  | 46-101905-02  | 46-101944-02  | 46-101905-02  | 46-101944-02  | 46-101905-02  |
|                         |       | Power Factor Choke                                   | N/A           | 46-24256-04   | N/A           | 46-24256-04   | N/A           |
| 18                      | Stk   | Control Board  | 47-102077-02  | 47-102077-02  | 47-102077-02  | 47-102077-02  | 47-102077-02  |
|                         | Stk   | Fuse - Control Board                                 | 44-101986-01  | 44-101986-01  | 44-101986-01  | 44-101986-01  | 44-101986-01  |
|                         |       | Wiring Harness - 6 pin to 6 strip leads (For T-Stat) | 45-101891-01  | 45-101891-01  | 45-101891-01  | 45-101891-01  | 45-101891-01  |
| 11                      |       | Terminal Block                                       | 45-23222-02   | 45-23222-02   | 45-23222-02   | 45-23222-02   | 45-23222-02   |

| No.                 | Notes | MODEL<br>CAPACITY<br>CABINET SIZE<br>VOLTAGE | RHLA                 | RHLA          | RHLA          | RHLA          | RHLA          |
|---------------------|-------|--|----------------------|---------------|---------------|---------------|---------------|
|                     |       |  | 24<br>17<br>A        | 24<br>17<br>J | 36<br>17<br>A | 36<br>17<br>J | 48<br>21<br>A |
| <b>BLOWER GROUP</b> |       |  |                      |               |               |               |               |
| 15                  | Stk   | Blower Assembly (Includes items 16-22)       | AS-101930-01         | AS-101886-01  | AS-101930-02  | AS-101886-02  | AS-101930-03  |
| 16                  |       | Mounting Bracket - Control Board             | AE-101049-01         | AE-101049-01  | AE-101049-01  | AE-101049-01  | AE-101049-01  |
| 17                  |       | Transformer                                  | See Electrical Group |               |               |               |               |
| 18                  |       | Control Board                                | See Electrical Group |               |               |               |               |
| 19                  |       | Blower Housing w/Wheel                       | 70-101729-01         | 70-101729-01  | 70-101729-02  | 70-101729-02  | 70-101729-03  |
|                     | Stk   | Blower Wheel                                 | 703012               | 703012        | 703014        | 703014        | 703013        |
| 20                  |       | Motor Mount - Band                           | 70-19927-04          | 70-19927-04   | 70-19927-04   | 70-19927-04   | 70-19927-04   |
| 21                  |       | Motor Mount - Arm (4)                        | 70-19929-10          | 70-19929-10   | 70-19929-10   | 70-19929-10   | 70-19929-10   |
| 22                  | Stk   | Blower Motor (X-13)                          | 51-102171-01         | 51-101879-01  | 51-102172-01  | 51-101880-01  | 51-102173-01  |
| 23                  |       | Mounting Bracket Cover                       | AE-101797-01         | AE-101797-01  | AE-101797-01  | AE-101797-01  | AE-101797-01  |

| No.                 | Notes | MODEL<br>CAPACITY<br>CABINET SIZE<br>VOLTAGE | RHLA                 | RHLA          | RHLA          | RHLA          | RHLA          |
|---------------------|-------|--|----------------------|---------------|---------------|---------------|---------------|
|                     |       |  | 48<br>21<br>J        | 48<br>24<br>A | 48<br>24<br>J | 60<br>24<br>A | 60<br>24<br>J |
| <b>BLOWER GROUP</b> |       |  |                      |               |               |               |               |
| 15                  | Stk   | Blower Assembly (Includes items 16-22)       | AS-101886-03         | AS-101930-04  | AS-101886-04  | AS-101930-04  | AS-101886-04  |
| 16                  |       | Mounting Bracket - Control Board             | AE-101049-01         | AE-101049-01  | AE-101049-01  | AE-101049-01  | AE-101049-01  |
| 17                  |       | Transformer                                  | See Electrical Group |               |               |               |               |
| 18                  |       | Control Board                                | See Electrical Group |               |               |               |               |
| 19                  |       | Blower Housing w/Wheel                       | 70-101729-03         | 70-101729-04  | 70-101729-04  | 70-101729-04  | 70-101729-04  |
|                     | Stk   | Blower Wheel                                 | 703013               | 703015        | 703015        | 703015        | 703015        |
| 20                  |       | Motor Mount - Band                           | 70-19927-04          | 70-19927-04   | 70-19927-04   | 70-19927-04   | 70-19927-04   |
| 21                  |       | Motor Mount - Arm (4)                        | 70-19929-10          | 70-19929-10   | 70-19929-10   | 70-19929-10   | 70-19929-10   |
| 22                  | Stk   | Blower Motor (X-13)                          | 51-101920-01         | 51-102173-02  | 51-101920-02  | 51-102173-02  | 51-101920-02  |
| 23                  |       | Mounting Bracket Cover                       | AE-101797-01         | AE-101797-01  | AE-101797-01  | AE-101797-01  | AE-101797-01  |