



# RGDJ

Parts List  
14-August-2014



*This parts list is current as of the above revision date.  
See <http://www.rheempartslists.net/92-42800-RGDJ.pdf> for the current revision.*

**80% Gas Furnaces**

No.	Notes	MODEL HEATING CAPACITY VARIATION BLOWER DESIGNATION	RGDJ- 05 A U	RGDJ- 07 A M	RGDJ- 07 A U
<b>PANELS, MISCELLANEOUS PARTS</b>					
1		Jacket	AS-61690-12	AS-61690-13	AS-61690-14
2		Top Plate	AE-61657-01	AE-61657-02	AE-61657-02
3		Blower/Filter Door	AE-61679-01	AE-61680-01	AE-61680-01
4		Burner Door (w/o Plug Buttons)	AE-61675-01	AE-61676-01	AE-61676-01
		Plug Button - 1-3/16 in opening (2)	45-22980-01	45-22980-01	45-22980-01
5		Control Box (w/o components)	68-22857-01	68-22857-01	68-22857-01
		Control Box Cover	AE-61699-02	AE-61699-02	AE-61699-02
		Silicone Tubing - Pressure Switch	79-21491-93	79-21491-93	79-21491-93
12		Integrated Furnace Control Board (IFC)	See Gas Controls		
13		Pressure Switch	See Electrical Group		
14		Door Switch - Push Button	See Electrical Group		
15		Limit - Main Limit (Heat Exchanger Panel)	See Electrical Group		
16		Limit - Manual Reset (Burner Compartment)	See Electrical Group		
17		Transformer	See Electrical Group		
18		Capacitor - Blower Motor	See Blower Group		
19		Induced Draft Blower w/Gasket	See Electrical Group		
25		Gas Valve	See Gas Controls		
26		Ignitor	See Gas Controls		

No.	Notes	MODEL HEATING CAPACITY VARIATION BLOWER DESIGNATION	RGDJ- 10 A M	RGDJ- 10 B R	RGDJ- 12 A R	RGDJ- 15 A R
<b>PANELS, MISCELLANEOUS PARTS</b>						
1		Jacket	AS-61690-13	AS-61690-15	AS-61690-16	AS-61690-16
2		Top Plate	AE-61657-02	AE-61657-03	AE-61657-04	AE-61657-04
3		Blower/Filter Door	AE-61680-01	AE-61681-01	AE-61682-01	AE-61682-01
4		Burner Door (w/o Plug Buttons)	AE-61676-01	AE-61677-01	AE-61678-01	AE-61678-01
		Plug Button - 1-3/16 in opening (2)	45-22980-01	45-22980-01	45-22980-01	45-22980-01
5		Control Box (w/o components)	68-22857-01	68-22857-01	68-22857-01	68-22857-01
		Control Box Cover	AE-61699-02	AE-61699-02	AE-61699-02	AE-61699-02
		Silicone Tubing - Pressure Switch	79-21491-93	79-21491-93	79-21491-83	79-21491-83
12		Integrated Furnace Control Board (IFC)	See Gas Controls			
13		Pressure Switch	See Electrical Group			
14		Door Switch - Push Button	See Electrical Group			
15		Limit - Main Limit (Heat Exchanger Panel)	See Electrical Group			
16		Limit - Manual Reset (Burner Compartment)	See Electrical Group			
17		Transformer	See Electrical Group			
18		Capacitor - Blower Motor	See Blower Group			
19		Induced Draft Blower w/Gasket	See Electrical Group			
25		Gas Valve	See Gas Controls			
26		Ignitor	See Gas Controls			