



# GEN30NG-GEN30LP

Parts List  
01-August-2008



*This parts list is current as of the above revision date.  
See <http://www.rheempartslists.net/92-42801-GEN30NG-GEN30LP.pdf> for the current revision.*

**Standby Generators**

No.	Notes	MODEL OUTPUT CAPACITY SERIES	GEN 30 NG/LP
<b>GENERAL ASSEMBLY PARTS</b>			
1		Base - Mounting	X203030GS
2		Mount - Vibration	187594GS
3		Hex Head Screw - Trilobular 5/16 - 18 X 1/2	CALL
4	Stk	Solenoid - Gas Fuel	194683GS
5		Fitting - Coupling	194829GS
6	Stk	Regulator	194830GS
7	Stk	Bracket - Mounting Solenoid	195936GS
8		Fitting - 3/4 Flare to 3/8 NPT	202382GS
9	2	Hex Head Cap Screw - M6 - 1.0 x 16	N/A
10	2	Hex Head Cap Screw - M6 - 1.0 x 30	N/A
11	2	Washer - 1/4 Lock	N/A
12	2	Nut - M6 - 1.0	N/A
13		Hex Head Screw - Trilobular - 1/4 - 20 x 1/2	CALL
14	Stk	Battery	194818GS
15		Wire - A - Black	CALL
16		Kit - Battery Hardware	198913GS
17		Wire - A - Red	CALL
18		Tube - Air Cleaner	CALL
19		Hex Head Screw - Trilobular - 1/4-20 x 7/8	CALL
20		Washer - Flat 5/16 - M8	N/A
21	Stk	Valve - Oil Drain (Before 3/10/2008)	1723165SM
21	Stk	Valve - Oil Drain (After 3/10/2008)	1723165SM
22		Clamp - Hose Band	CALL
23		Hose - Oil Drain	1723165SM
24		Decal - Oil Drain	1723165SM
25	2	Hex Head Cap Screw - 5/16 - 18 x 2.5 Full Thread	N/A
26	2	Nut - 5/16 - 18	N/A
27	2	Washer - Lock 5/16 - M8	N/A
28		Wire	186790CGS
29	2	Hex Head Cap Screw - 5/16 - 18 x 2 in. Lg.	N/A
30	2	Hex Head Cap Screw - M12 - 1.75 x 35	N/A
31	2	Washer - M12	N/A
32		Support - Engine/Alternator - Black	CALL
33		Screen	202922GS
34	2	Washer - Shakeproof Ext. M6-1/4	N/A
35		Wire - Ground	CALL
36	2	Washer - Lock 3/8	N/A
37	2	Washer - M10 - Flat 3/8	N/A
38	2	Hex Head Cap Screw - 3/8 - 16 x 1	N/A
39		Bracket - Alternator Mounting - Black	CALL
40		Duct - Air	CALL
41	2	Screw - M5.8 x 10 - Taptite	N/A
42	2	Washer - Lock 3/8	N/A
43	2	Square Head Cap Screw - 3/8 - 16 x 1-1/4	N/A
44	2	Hex Head Cap Screw - 5/16 - 18 x 3/4	N/A