

No.	Notes	MODEL OUTPUT CAPACITY SERIES	GEN 30 NG/LP
GENERAL ASSEMBLY PARTS (CONTINUED)			
45		Hex Head Screw - Trilobular - 1/4 - 20 x 1/2	CALL
46	2	Phillips Pan Head Machine Screw - 4-40 x 0.19	N/A
47	2	Washer - Lock #4	N/A
48	Stk	Switch - Oil Temperature	186205GS
49		Plate - Switch Oil Temperature	194699GS
50		Screw	CALL
51	1	Assembly - Alternator (See 202820)	N/A
52		Square Head Cap Screw - M8 - 1.25 x 20	CALL
53		Decal - Caution Hot Surface	CALL
54		Gasket	807208
55		Muffler	202885GS
56		Base - Muffler Box	CALL
57		Kit - Insulation - Muffler Box Base	CALL
58		Crimptite - 10 - 24 x 1/2	CALL
59		Assembly - Bulkhead - Alternator End w/Insulation	203085GS
60		Kit - Insulation - Muffler Box Top	CALL
61		Collector - Muffler Box	CALL
62		Box - Muffler Top	CALL
63		Screw - 10 - 32 x 5/8	CALL
64	2	Washer - Shakeproof M6	N/A
900		Engine	613275-0155-E1
901	Stk	Fuel Hose w/Clamp	842185

	Notes	MODEL OUTPUT CAPACITY SERIES	GEN 30 NG/LP
GENERAL ASSEMBLY PARTS - NOT PICTURED			
		Manual - Install	202994GS
		Manual - Operators	202993GS
		Manual - Engine	MS3483
		Kit - Manual/Accessory	203194GS
	Stk	Cap - Funnel Oil Bottle	B3518GS
	Stk	Hose - Flex	202295GS
	Stk	Kit - LED Remote	198866GS
		Manual	202996GS
		Kit - Decals	204014GS
	3,Stk	Kit - Cold Weather (Includes Battery and Oil Warmer)	6030