

Pilot Assembly & Pilot Burners

Pilot Assembly: Flammable Vapor

Part Number	NEW Part Number	Description	Gas Type
9003510005	100109276	FV Pilot Assembly, 140°	Natural
9004021005	100109671	FV Pilot Assembly, 140°	Propane
9004324005	100109793	FV Pilot Assembly, 150°	Natural
9003540005	100109293	FV Pilot Assembly, 160°	Natural
9003541005	100109294	FV Pilot Assembly, 160°	Propane
9003488005	100109261	FV Pilot Assembly, 170°	Natural
9003472005	100109253	FV Pilot Assembly, 170°	Propane
9003531005	100109290	FV Pilot Assembly, 180°	Natural
9003455005	100109243	FV Pilot Assembly, 180°	Propane
9003542005	100109295	FV Pilot Assembly, 190°	Natural
9003543005	100109297	FV Pilot Assembly, 190°	Propane
9003521005	100109286	FV Pilot Assembly, 200°	Natural
9003544005	100109298	FV Pilot Assembly, 200°	Propane

Pilot Burners: Commercial

Part Number	NEW Part Number	Description	Gas Type
9004542215	100109928	Pilot Burner for BTC-120 thru 500A series 970 and up.	Propane
9004541215	100109926	Pilot Burner for BTC-120 thru 500A series 970 and up.	Propane
9004988115	100110196	Pilot Burner for use on I.I.D. model heaters	Propane
9004989115	100110197	Pilot Burner for use on I.I.D. model heaters	Propane
9005043115	100110232	750 Millivolt Thermopile, 32" long	---
9004771115	100110073	30 Millivolt Thermocouple, 36" long with junction block	---
9004534215	100109921	Pilot Burner for use on BTC models series 962	Natural
9004532215	100109919	Pilot Burner for use on BTC models series 963	Propane
9003319005	100109155	Pilot Assembly, PB-5P with 24" Leads	Propane
9003320005	100109156	Pilot Assembly, PB-5P with 24" Leads	Natural
9003925115	100109617	Aluminum Tubing, 60" length. Use when tubing has been damaged or is too short after control replacement. (includes 2 Fittings)	---

