



Dryer Parts

DRYER ELEMENTS

- Direct Replacement Elements

PART NO.	WATTS	VOLTS	REPLACES
DE138	5300	240	Maytag® 303404
DE148	4750	240	Maytag® LA-1044
DE698	5200	240	Whirlpool® 4391960
DE838	5400	240	GE® WE11X10004, Whirlpool® 279838
DE0019A	5300	240	Samsung® DC47-00019A
DE1001	5400	240	LG® 6931EL1001
DE4771	5400	240	Whirlpool® 8544771
DE7747	5200	240	Whirlpool® 3387747



APPLIANCE

DRYER RESTRING KITS

- Direct Replacement Restring Kits

PART NO.	REPLACES
DE315	GE® WE11X60
DE333	GE® WE11X203
DE334	GE® WE11M21C
DE335	Electrolux® 5300622032
DE336	Electrolux® 5300622034
DE1746C	Maytag® 31001746C
DE019AC	LG® DC47-00019A



DE1746C

DE315

DRYER IGNITERS

- Includes Mounting Hardware Where Necessary

PART NO.	STYLE	REPLACES
SDE350	Round	GEM® DE350, ADC® 128910 and More
SDE358	Round	Gem® DE359, GE® WE4X739 and More
SDE359	Round	Gem® DE359, DE363, Amana® 40069801P and More
SDE365	Round	LG® 5318EL3W1A
SDE364	Flat	Whirlpool® 4391996, Glo Bar® 304970 and More
SDE366	Flat	Maytag® 31001556 and More



SDE358



SDE364

FLAME SENSORS

- Exact Replacement Dryer Flame Sensor for Many OEM Brands
- Senses Igniter for Heat and Opens Gas Valve for Burner
- Safety Device in Flame Out Condition

PART NO.	REPLACES
DE353	Whirlpool® 338906
DE355	GE® WE4X448



DE353



DE355