Tech Tip Measuring Superheat and Subcool




Our Technical department has asked that certain information be documented prior to calling them for help on refrigeration problems.

Superheat and Subcooling are vital signs of the system in the same way the doctor uses blood pressure to assess someone's health. The request may come in a format something like this:

Formula For Super Heat	Formula For Sub Cooling
Vapor Line Temp.	Sat Temp.
Minus Sat Temp.	Minus Liquid Line Temp.
Equals Super Heat	Equals

SUPERHEAT

The Vapor Line Temperature is measured on the large suction line near the condensing unit (A). Many refrigeration personnel will measure at the outlet of the evaporator but in HVAC you are more concerned with protecting the compressor than



maintaining full capacity of the evaporator coil. Connecting a clamp thermometer in the shade, on the vapor line, will achieve this reading. Allow 5-10 minutes of run time to allow system to balance. For our example the Vapor Line


Temp is 53 degrees. Next step is to "Minus Sat Temp". The Saturation Temperature is

located on the gauge on this



SUBCOOL

The Saturation temperature for Subcooling is acquired from the high side gauge. In this example the Sat Temp is about 110 degrees. Next is to "Minus Liquid Line Temp". The Liquid Line Temperature is also measured at the outlet of the condensing unit but now is measured on the small liquid line (B). For this example the Liquid line Temp is 95 degrees. Subtract the Liquid line Temperature from the Liquid Saturation Temperature and you get a Subcooling of 15.



"Typically" on TXV systems the Superheat will range between 8 to 28 degrees with a target of about 10 to 15 degrees. The Subcool range on TXV systems will range from about 8 to 20. Although this is not enough information to charge a system, it does give a technician a better understanding of the systems operation.

Again, follow manufacturers' recommendations for charging!