

# MODEL: S96VA Multi-Position Gas Furnaces

FORM NO. GSC-540 REV. 3



# Sure Comfort® S96VA 96% A.F.U.E. Two-Stage Variable Speed Multi-Position Gas Furnaces

 Models with Input Rates from 40 to 115 kBTU [11.72 to 33.71 kW]











All Models except S96VA085


- 96% residential gas furnace CSA certified
- 4 way multi-poise design
- Two stages of operation to save energy and maintain optimal comfort level.
- Variable speed blower motor technology provides ultimate humidity control, quieter sound levels, and year round energy savings.
- 7-Segment LED all units
- · Direct Spark Ignition for reliability and longevity
- Water Management System with patented Blocked Drain Sensor
- Heat exchanger is removable for improved serviceability. Aluminized steel primary and stainless steel secondary construction provide maximum corrosion resistance and thermal fatigue reliability.
- Low profile "34 inch" cabinet ideal for space constrained installations.

- Blower Shelf design serviceable in all furnace orientations
- Pre marked hoses insures proper system drainage
- Vent with 2" or 3" PVC
- Replaceable Collector box
- Hemmed edges on cabinet and doors
- Quarter turn fasteners for tool less access
- Integrated control boards feature dip switches for easy system set up
- Self priming condensate trap
- Solid bottom included
- Compatible with single or two stage thermostats. For optimal performance a two stage thermostat is recommended.

†A.F.U.E. (Annual Fuel Utilization Efficiency) calculated in accordance with Department of Energy test procedures.

## **Table of Contents**

Standard & Optional Equipment
Physical Data & Specifications
Model Number Identification
Dimensional Data
Blower Performance Data
Accessories.
Limited Warranty



#### STANDARD EQUIPMENT

Completely assembled and wired; blocked drain sensor, 7 segment LED and marked hoses; heat exchanger; primary: aluminized steel, secondary: 29-4C stainless steel; 2 stage induced draft; pressure switches; redundant 2 stage main gas control; blower compartment door safety switch; solid state time on/off blower control; limit controls; manual shut-off valve; 100% safety lock out; cool fan off delay; field selectable heat fan off delay; one hour automatic retry; power and self-test diagnostics; flame sense current diagnostics; electronic air cleaner connections; twinning (built-in) features; humidifier connections; humidifier on/off delay; low speed continuous fan option; single speed option for heating and cooling applications; transformer; direct drive, multi-speed blower motor. Solid bottom. (Please note: a thermostat is not included as standard equipment.)

#### **OPTIONAL EQUIPMENT**

Side and bottom filter racks; return air cabinet for all sizes.

NOTE: Furnace is not listed for use with fuels other than natural or L.P. (propane) gas.

All models can be converted by a qualified distributor or local service dealer to use L.P. (propane) gas without changing burners. Factory approved kits must be used to convert from natural to L.P. (propane) gas and may be ordered as optional accessories from a parts distributor.

For L.P. (propane) operation, refer to Conversion Kit Index Form.

# WARNING

THIS FURNACE IS NOT APPROVED OR RECOMMENDED FOR USE IN MOBILE HOMES

www.SureComfort.com \_\_\_\_\_\_\_

# Physical Data and Specifications—Upflow Models U.S. and Canadian Models

MODEL NUMBERS	S96VA0402317MSA	S96VA0602317MSA	S96VA0702317MSA	S96VA0852521MSB	S96VA1002521MSA	S96VA1152524MSA
HIGH FIRE INPUT BTU/HR [kW] ①	42,000 [12.31]	56,000 [16.41]	70,000 [20.50]	84,000 [24.61]	98,000 [28.72]	112,000 [32.82]
LOW FIRE INPUT	29,400 [8.61]	39,200 [11.49]	49,000 [14.36]	58,800 [17.23]	68,600 [20.11]	78,400 [23.00]
HEATING CAPACITY BTU/HR [kW]	41,000 [12.02]	55,000 [16.12]	68,000 [19.93]	82,000 [24.03]	95,000 [27.84]	109,000 [31.94]
HIGH ALTITUDE OUTPUT 10% DERATE [kW] ②	36,288 [10.64]	48,384 [14.18]	60,480 [17.72]	72,756 [21.27]	84,672 [24.81]	96,768 [28.36]
BLOWER (D x W) [mm]	11 x 7 [279 x 178]	11 x 8 [279 x 203]	11 x 8 [279 x 203]	11 x 10 [279 x 254]	11 x 10 [279 x 254]	11 x 11 [279 x 279]
MOTOR H.P. [W]- TYPE	1/2 [373] E.C.M.	1/2 [373] E.C.M.	1/2 [373] E.C.M.	3/4 [559] E.C.M.	3/4 [559] E.C.M.	3/4 [559] E.C.M.
MIN. CIRCUIT AMPACITY	8.00	7.00	9.00	12.00	12.00	12.00
MIN. OVERLOAD PROTECTION DEVICE	15.00	15.00	15.00	15.00	15.00	15.00
MAX. OVERLOAD PROTECTION DEVICE	15.00	15.00	15.00	20.00	20.00	15.00
MINIMUM EXT. STATIC PRESSURE (IN. W.C.) [kPa]	.18 [.045]	.20 [.050]	.23 [.057]	.28 [.070]	.28 [.070]	.28 [.070]
MAXIMUM EXT. STATIC PRESSURE (IN. W.C.) [kPa]	1.0 [0.249]	1.0 [0.249]	1.0 [0.249]	1.0 [0.249]	1.0 [0.249]	1.0 [0.249]
HEATING CFM @ .2" [.049 kPa] W.C. E.S.P. [L/s]	1050 [496]	1025 [484]	1015 [479]	1470 [694]	1710 [807]	1450 [684]
COOLING CFM @ .5" [.124 kPa] W.C. E.S.P. [L/s]	1050 [496]	1050 [496]	1050 [496]	1750 [826]	1750 [826]	1750 [826]
TEMPERATURE RISE-HIGH FIRE RANGE IN DEGREES °F [°C]	20 - 50 [11 - 28]	30 - 60 [17 - 33]	40 - 70 [22 - 39]	30 - 60 [17 - 33]	40 - 70 [22 - 39]	45 - 75 [25 - 42]
TEMPERATURE RISE-LOW FIRE RANGE IN DEGREES °F [°C]	15 - 45 [8 - 25]	20 - 50 [11 - 28]	30 - 60 [17 - 33]	20 - 50 [11 - 28]	30 - 60 [17 - 33]	35 - 63 [19 - 36]
APPROX. SHIPPING WEIGHT (LBS.) [kg]	128 [58]	128 [58]	132 [60]	147.5 [67]	152 [69]	165 [75]
AFUE ③	96.00%	96.00%	96.00%	96.00%	96.00%	96.00%

NOTES: All models are 115V, 60HZ, 1 phase Gas connection size for all models is 1/2" [13 mm] N.P.T.

① Installation installations only.
② Canadian installations only.

- In accordance with D.O.E. test procedures.\*S=Standard Models

NOTE: Standard model complies with California low nox requirements.


[ ] Designates Metric Conversions

# **Model Number Identification**

<u>s</u>	96	<u>v</u>	<u>A</u>	<u> </u>	<u>2</u>	<u>3</u>	<u>17</u>	<u>M</u>	<u>s</u>	<u>A</u>
Sure Comfort	96% Efficient	Motor - ECM	Design Series A = 1st Design	Input <u>BTU/HR</u> 040 = 42,000 [12.31 060 = 56,000 [16.41 070 = 70,000 [20.51 085 = 84,000 [24.62 100 = 98,000 [28.72 115 = 112,000 [32.82	kW] kW] kW] kW]	Airflow 3 - Up to 3 Tons 5 - Up to 5 Tons	17 = 17.5"	Configuration - Multi-Position	S = Standard $N = NOx$	Revision - Marketing (A - First Time Release) (B - First Revision)

<sup>[ ]</sup> Designates Metric Conversions

www.SureComfort.com \_\_\_\_\_\_ 5



# UNIT DIMENSIONS (CLEARANCE TO COMBUSTIBLES)

MODEL LEFT S96V SIDE		MINIMUM	CLEARANCE	(IN.) [mm]		SHIP	FLANGE DIMENSIONS			
	RIGHT SIDE	BACK	TOP	FRONT	VENT	WGTS.	Α	В	С	
040	0	0	0	1 [25]	2 [51]	0	123.5 [56]	17 <sup>1</sup> / <sub>2</sub> [445]	16 <sup>17</sup> / <sub>64</sub> [413]	16 <sup>13</sup> /64 [412]
060	0	0	0	1 [25]	2 [51]	0	128 [58]	171/2 [445]	16 <sup>17</sup> / <sub>64</sub> [413]	16 <sup>13</sup> /64 [412]
070	0	0	0	1 [25]	2 [51]	0	132 [60]	171/2 [445]	16 <sup>17</sup> / <sub>64</sub> [413]	16 <sup>13</sup> /64 [412]
085	0	0	0	1 [25]	2 [51]	0	147.5 [67]	21 [533]	19 <sup>49</sup> / <sub>64</sub> [502]	19 <sup>45</sup> /64 [500]
100	0	0	0	1 [25]	2 [51]	0	152 [69]	21 [533]	19 <sup>49</sup> / <sub>64</sub> [502]	19 <sup>45</sup> /64 [500]
115	0	0	0	1 [25]	2 [51]	0	165 [75]	241/2 [662]	2317/64 [591]	23 <sup>13</sup> /64 [589]

<sup>\*</sup>A service clearance of at least 24" is recommended in front of all furnaces

[ ] Designates Metric Conversions

Supply and return depicted as upflow configuration.

Flange configuration will vary depending on installation orientation.

	MODEL NU	JMBER		S96VA0402317MSA	S96VA0602317MSA	S96VA0702317MSA	S96VA0852521MSB	S96VA1002521MSA	S96VA115524MSA
		SW 15 = OFF	SW 16 = OFF	1050 [496]	1025 [484]	1015 [479]	1470 [694]	1710 [807]	1450 [684]
	HIGH HEATING	SW ON = ON	SW 16 = OFF	800 [378]	880 [415]	950 [448]	1235 [583]	1490 [703]	1300 [614]
	CFM [L/s]	SW 15 = OFF	SW 16 = ON	1200 [566]	1250 [590]	1190 [562]	1850 [873]	1965 [927]	1700 [802]
TARGET GAS		SW 15 = ON	SW 16 = ON	700 [330]	780 [368]	900 [425]	1120 [529]	1400 [661]	1225 [578]
HEATING AIRFLOW		SW 13 = OFF	SW 14 = OFF	910 [429]	925 [437]	900 [425]	1300 [614]	1500 [708]	1250 [590]
	LOW HEATING	SW 13 = ON	SW 14 = OFF	690 [326]	750 [354]	770 [363]	1065 [503]	1335 [630]	1060 [500]
	CFM [L/s]	SW 13 = OFF	SW 14 = ON	1040 [491]	1210 [571]	1050 [496]	1775 [838]	1800 [850]	1400 [661]
		SW 13 = ON	SW 14 = ON	607 [286]	660 [311]	700 [330]	925 [437]	1210 [571]	960 [453]
	HIGH COOLING	SW 4 = OFF	SW 5 = OFF	1050 [496]	1050 [496]	1050 [496]	1750 [826]	1750 [826]	1750 [826]
		SW 4 = ON	SW 5 = OFF	875 [413]	875 [413]	875 [413]	1400 [661]	1400 [661]	1400 [661]
	CFM [L/s]	SW 4 = OFF	SW 5 = ON	700 [330]	700 [330]	700 [330]	1225 [578]	1225 [578]	1225 [578]
TARGET COOLING/		SW 4 = ON	SW 5 = ON	525 [248]	525 [248]	525 [248]	1050 [496]	1050 [496]	1050 [496]
		SW 4 = OFF	SW 5 = OFF	788 [372]	788 [372]	788 [372]	1313 [619]	1313 [619]	1313 [619]
	LOW COOLING CFM [L/s]	SW 4 = ON	SW 5 = OFF	656 [310]	656 [310]	656 [310]	1050 [496]	1050 [496]	1050 [496]
		SW 4 = OFF	SW 5 = ON	525 [248]	525 [248]	525 [248]	919 [434]	919 [434]	919 [434]
		SW 4 = ON	SW 5 = ON	394 [186]	394 [186]	394 [186]	788 [372]	788 [372]	788 [372]

 $^{\star}\text{S} = \text{Standard Models}$  NOTE Standard model complies with California low NOx requirements.

[ ] Designates Metric Conversions.

#### **VENT TERMINATION KITS: =**

**RXGY-E02:** Vertical/Horizontal Concentric Vent Termination Kit 2" Pipe (US Only)

**RXGY-E02A:** Vertical/Horizontal Concentric Vent Termination Kit 2" Pipe (US & Canadian)

**RXGY-E03:** Vertical/Horizontal Concentric Vent Termination Kit 3" Pipe (US Only)

**RXGY-E03A:** Vertical/Horizontal Concentric Vent Termination Kit 3" Pipe (US & Canadian)

RXGY-G02: Direct Vent Furnace Side Wall Vent 2" or 3" (US Only)

RXGY-D05: Combustion Air Drain Kit 2"
RXGY-D06: Combustion Air Drain Kit 3"

**NEUTRALIZER KIT: RXGY-A01** 

(Replacement Cartridge 54-22120-01) **RETURN AIR PLENUM:** RXGR-C17B

RXGR-C21B RXGR-C24B

EXTERNAL BOTTOM FILTER (UPFLOW/HORIZONTAL) RACK:

**RXGF-CB** 

EXTERNAL SIDE (UPFLOW) FILTER RACK: RXGF-CD EXTERNAL (DOWNFLOW) FILTER RACK: RXGF-CC

	FILTER RACK FILTER SIZES* INCHES [mm]									
MODEL	RXGF-CB (UPFLOW/ HORIZONTAL)	RXGF-CD (UPFLOW)	RXGF-CC (DOWNFLOW)							
S96VA040	15 <sup>3</sup> / <sub>4</sub> x 25	15 <sup>3</sup> / <sub>4</sub> x 25	12 x 20							
	[400 x 635]	[400 x 635]	[305 x 508]							
S96VA060	15 <sup>3</sup> / <sub>4</sub> x 25	15 <sup>3</sup> / <sub>4</sub> x 25	12 x 20							
	[400 x 635]	[400 x 635]	[305 x 508]							
S96VA070	15 <sup>3</sup> / <sub>4</sub> x 25	15 <sup>3</sup> / <sub>4</sub> x 25	12 x 20							
	[400 x 635]	[400 x 635]	[305 x 508]							
S96VA085	19 <sup>1</sup> / <sub>4</sub> x 25	15 <sup>3</sup> / <sub>4</sub> x 25	12 x 20							
	[489 x 635]	[400 x 635]	[305 x 508]							
S96VA100	19 <sup>1</sup> / <sub>4</sub> x 25	15 <sup>3</sup> / <sub>4</sub> x 25	12 x 20							
	[489 x 635]	[400 x 635]	[305 x 508]							
S96VA115	22 <sup>3</sup> / <sub>4</sub> x 25	15 <sup>3</sup> / <sub>4</sub> x 25	14 x 20							
	[578 x 635]	[400 x 635]	[356 x 508]							

<sup>\*</sup>Filter racks are shipped without filters.

#### INDOOR COIL CASINGS

MODEL NUMBER
RXBC-D17A1
RXBC-D21A1
RXBC-D21B1
RXBC-D24A1

#### FOR HIGH ALTITUDES:

**NOTE:** For Canadian installations only, an optional derate (manifold gas pressure reduction) method may be used to adjust the furnace for altitude. See Installation Instructions for more information. This optional method may **NOT** be used for U.S. installations. See installation instructions as appropriate orifice change is required.

L.P. CONVERSION KIT: RXGJ-FP34

**RETURN AIR PLENUM KIT: RXGR-C17B** 

RXGR-C21B RXGR-C24B

CONDENSATE PUMP KIT: PROSTOCK & 1PCB151TUL DOWNFLOW/HORIZONTAL CONVERSION KIT: RXGY-CK

DOWNFLOW/HORIZONTAL LEFT ZERO CLEARANCE CONVERSION KIT: RXGY-ZK

**COMBUSTIBLE FLOOR BASE: RXGC-B17** 

RXGC-B21 RXGC-B24

[ ] Designates Metric Conversions

Filters shipped with furnace may be used or a suitable 1" [25.4 mm] filter.

CHE	Camfart	B COZVA	Multi-Posi	tion Car	Eurpaca
Silice		SYNVA	MIIIII-POSI	HION GAS	

## **GENERAL TERMS OF LIMITED WARRANTY\***

Sure Comfort® will furnish a replacement for any part of this product which fails in normal use and service within the applicable period stated, in accordance with the terms of the limited warranty.

\*For complete details of the Limited and Conditional Warranties, including applicable terms and conditions, contact your local contractor or the Manufacturer for a copy of the product warranty certificate.

Parts ...... Ten (10) Years
Heat Exchanger ..... Limited Lifetime
Conditional Unit Replacement ..... Ten (10) Years

www.SureComfort.com



10 \_\_\_\_\_ www.SureComfort.com

www.SureComfort.com



Sure Comfort®

Before proceeding with installation, refer to installation instructions packaged with each model, as well as complying with all Federal, State, Provincial, and Local codes, regulations, and practices.